

Contents

Preface	xix
Acknowledgments	xxi

Chapter 1

Introduction to Well Logs and Terminology	1
Well Information	1
API Numbering	3
State code	5
County code	6
Well number	6
Sidetrack code	6
Event code	6
Subsurface Thicknesses	6
Exercises	12
Questions	14

Chapter 2

Basic Well Logs and Log Signatures	15
Basic Well Log Types	15
Gamma ray (GR)	16
Resistivity	16
Spontaneous potential (SP)	16
Photoelectric (PE)	18
Neutron	18
Density	18
Dipmeter	19
Caliper	19
Sonic (acoustic)	19
Temperature	21
Lithology	22
Log Signature Patterns	23
Exercise	25
Questions	31

Chapter 3

Introduction to Subsurface Maps and Contouring 33

 Contouring 33

 Data Posting 37

 Contouring Algorithms. 39

 Cokriging. 40

 Gridding. 42

 Exercises. 45

 Questions. 48

Chapter 4

Structural and Stratigraphic Interpretations 49

 Picking Methodology. 49

 Structural Interpretations. 52

 Stratigraphic Interpretations 53

 Unconformities and Erosion Estimates 55

 Exercise. 59

 Questions. 67

Chapter 5

Structure Contour Maps 69

 Fetch Maps. 72

 Exercise. 74

 Questions. 87

Chapter 6

Thickness Maps 89

 Isopach vs. Isochore. 89

 Net Pay 91

 Exercise. 94

 Questions. 106

Chapter 7

Facies Maps 107

 Paleogeographic and Paleoenvironmental Maps. 110

 Exercise. 112

 Questions. 124

Chapter 8

Trend Surface Maps 125

 Three-Point Problems 126

 Exercise. 129

 Questions. 134

Chapter 9

Trend Surface Residual Anomaly Maps	135
Making a TSRA Map	135
Exercise	140
Questions	152

Chapter 10

Hydrologic Maps and Injection Wells	153
Hydrologic Maps	153
Injection Wells	154
Exercises	164
Questions	169

Chapter 11

Spectral Gamma Ray Logs and Fault Seal	171
Spectral Gamma Ray Logs	171
Source Rocks and Clay Types	172
Core-Log Depth Shifts	172
V_{shale} and V_{clay}	174
Fault Basics and Terminology	175
Spill and Leak Points	177
Fault Seal Mechanisms and Controls	180
Fault Seal Techniques and Algorithms	182
Exercise	185
Questions	187

Chapter 12

Cross Sections	189
Cross Section Types	189
Contour Slicing	190
Vertical Exaggeration	192
Balanced Cross Sections	193
One-Dimensional Burial History Models	197
Exercises	200
Questions	207

Chapter 13

Unconventionals and Source Rock Maps	209
Unconventional Resources	209
Migrated vs. Retained Unconventional Plays	211
Source Rock Identification	213
Unconventional Maps	215
TOC maps	215

Organofacies maps	218
Thermal maturity maps	221
Rock-Eval	223
Total organic carbon (TOC)	223
S1	224
S2	224
S3	224
T _{max}	224
Production index (PI)	225
Hydrogen index (HI)	225
Oxygen index (OI)	226
Oil saturation index (OSI)	226
Horizontal Drilling and In-Situ Stress	226
Exercise	232
Questions	233

Chapter 14

Mining Maps	235
Calculating Mining Resources and Reserves	235
Exercise	238
Questions	240

Chapter 15

Geothermal and Temperature Maps	241
Temperature Maps	242
Bottom-Hole Temperature Corrections	243
Thermal Modeling	244
Geothermal Resources	246
Exercise	249
Questions	251

Chapter 16

Formation Fluid Interpretation and Hydrocarbon Reserves	253
Water Saturation Calculations	256
Calculating Hydrocarbon Resources and Reserves	257
Reservoir Drive Mechanisms and Recovery Factors	262
Exercises	264
Questions	266

Appendix A

Probability and Uncertainty	267
Exercise	268
Questions	270

Appendix B

Swan Creek Term Project 271

 Exercise..... 272

 Questions..... 294

Glossary 295

List of Abbreviations 303

Bibliography..... 309

15

Geothermal and Temperature Maps

Temperature variability within the Earth is an important factor that impacts a wide range of fields. Temperature data are commonly used in geothermal energy assessments, source rock maturity estimates, reservoir diagenetic models, porosity-permeability estimates, mining operational depths, fault detection, resource estimates, and identification of drilling depths or floors at which tools can no longer operate, among other purposes. There are many ways to gather temperature data, from satellites to deep wellbores that penetrate oceanic or continental crust. Most wells fortunately contain temperature data in the form of a maximum bottom-hole temperature (BHT) found within the well header. Many operators also run a continuous temperature log, but these data are more difficult to collate. The most difficult data to collect are often thermal conductivity data, which are required to do thermal modeling. In areas without subsurface data, it is common to use a geothermal gradient of $\sim 25^{\circ}\text{C}/\text{km}$, which is a typical gradient for wells on continental crust. The average heat flow value for continental crust is $\sim 65 \text{ mW}/\text{m}^2$. These values cannot be used for wells on oceanic crust, where values are usually lower, but can be considerably higher ($>100 \text{ mW}/\text{m}^2$). Heat flow on oceanic crust is a function of crustal age (Fowler 2012).

Temperature data are very valuable but can be underutilized for a number of reasons. These include issues related to corrections, differences in shallow vs. deep well measurements, reported heat flow calculations rather than temperature and thermal conductivity, seasonal-to-diurnal changes, nonunique modeling, the presence of thick salt units, and other data nuances. From a data standpoint, there are many good public domain sources that can be utilized. BHTs and geothermal gradient data are also found in many online resources and within some academic sources. Global satellite and climate data can be used to estimate the mean annual surface temperature, which is needed to calculate geothermal gradients and predict subsurface temperatures.

Temperature Maps

Three common temperature-related maps are: (1) geothermal gradients; (2) the temperature at a specific depth or horizon; and (3) the depth to a certain isotherm (fig. 15–1). Geothermal gradient maps illustrate the lateral variability in the subsurface heat flux, with the Earth’s surface as the datum. Typically, the gradient is calculated from ground level or sea bed to the bottom-hole temperature minus the average surface temperature. The units most commonly used are degrees Celsius per kilometer ($^{\circ}\text{C}/\text{km}$), but occasionally other units are used, such as degrees Fahrenheit per thousand feet ($^{\circ}\text{F}/1,000\text{ ft}$) or Kelvin per kilometer (K/km). A heat flow map is similar to the geothermal gradient map, except the heat flow data incorporate the thermal conductivity of the sediment or rock and will be reported in milliwatts per square meter (mW/m^2). It is not always clear what or how much thermal conductivity data were used to convert the temperature data, so it is recommended that the data and maps be kept separate.




Fig. 15–1. An example of subsurface isotherms and calculated geothermal gradients for onshore and offshore wells.

Another common temperature map is an estimation of temperatures at a depth or horizon. This can be thought of as a depth slice through a seismic volume at a consistent depth or as an attribute overlain on a surface with variable depths. These maps are very useful when dealing with temperature-related chemical reactions and variables sensitive to pressure and volume (e.g., resource estimates, reservoir

diagenetic models, porosity-permeability estimates, and source rock maturity estimates). Many of these transformations or reactions can occur very quickly at specific temperatures, and therefore it is important to recognize the error bars associated with the temperature measurements, the temperature corrections, and the depth to the horizon.

The last common type of temperature-related map is the depths to significant isotherms map, which is used to depict the depth at which a particular temperature occurs. This type of map can be used to high-grade areas that are more prospective to geothermal energy development, estimate the depth at which subsurface mining may no longer be feasible, or determine at what depths certain drilling and completion technologies may not work. The equations to calculate a geothermal gradient, temperatures at a depth or horizon, and isotherm depths are listed below as equations (15.1)–(15.3). There are no standard units, but it is important to use the same units (e.g., °C or °F, and feet or meters). Also, be careful in areas where the surface elevations are subsea, and in deviated or horizontal wells that only the TVD values are utilized.

$$\text{Geothermal gradient} = (\text{BHT}_c - T_{\text{surf}}) / Z \quad (15.1)$$

$$\begin{aligned} \text{Temperature at a depth or horizon} = &[(\text{Elv}_{\text{surf}} - \text{horizon depth in TVDss}) \\ &\times \text{geothermal gradient}] + T_{\text{surf}} \end{aligned} \quad (15.2)$$

$$\begin{aligned} \text{Isotherm depth} = &\text{Elv}_{\text{surf}} - [(\text{isotherm temperature} - T_{\text{surf}}) / \text{geothermal} \\ &\text{gradient}] \end{aligned} \quad (15.3)$$

where:

BHT_c = Corrected bottom-hole temperature

T_{surf} = Mean annual surface temperature

Z = TVD below ground level or seafloor

Elv_{surf} = Surface elevation

Bottom-Hole Temperature Corrections

BHTs need to be corrected if they are extracted from the well header, and this can be achieved using one of the many BHT correction equations, such as equation (15.4) from Waples et al. (2004). Most of the equations use the maximum BHT, the depth of the measurement, and the time since drilling fluids were last circulated. Occasionally, information regarding the borehole radius and conductivity information may be needed, but these data rarely significantly impact the estimates. In practice, deeper wells and wells that have more time to equilibrate with the ambient formation temperature have smaller correction factors. Wells that stop circulation and record the BHT within 24 hours can have corrections ~5°–10°C

(i.e., the formation temperature will be higher than the recorded BHT). Shallow wells (<1,000 meters), wells that encounter significant amounts of gas, and wells near salt bodies are prone to highly variable measurements due to the high thermal conductivity of salt, the cooling effect of gas expansion, and shallow influxes of meteoric water. If these conditions are present, the data will potentially need further interrogation to see if they are appropriate to use. For example, below thick salt intervals, the geothermal gradient is commonly less than the geothermal gradient above the salt unit. Therefore, it may not be appropriate to use one geothermal gradient for the entire wellbore depending on the purpose of the map. In this example, two separate geothermal gradients are commonly used (one suprasalt and one subsalt).

$$\text{Corrected BHT} = T_{\text{surf}} + 1.32866^{(-0.005289 \times \text{TSC})} \times (\text{measured BHT} - T_{\text{surf}}) - 0.001391 \times (Z - 4,498) \quad (15.4)$$

where:

BHT = Bottom-hole temperature (°C)

T_{surf} = Mean annual surface temperature (°C)

TSC = Time since mud was last circulated, recorded in the well header (hours)

Z = TVD below ground level or seafloor (meters)

Thermal Modeling

From a modeling perspective, temperatures measured within the lithosphere and sedimentary cover come from three main sources (the mantle, the upper crust, and sedimentary rocks). The thickness of the lithosphere typically is between 40 km and 140 km on oceanic crust and is thicker beneath continental crust (up to ~300 km). The source of geothermal heat is mainly from deep within the Earth and is caused by the decay of radioactive isotopes (mainly uranium, potassium, and thorium). The dominant controlling factor in surface heat flow is the depth to top of the asthenosphere and the thermal conductivities of the intervening rock intervals (fig. 15–2). Unfortunately, these are the least constrained modeling inputs (Allen and Allen 2005). Two perhaps underappreciated factors that impact thermal modeling are the sedimentary rate and the age of the sedimentary fill. Younger sediments and higher sedimentary rates tend to drive down the geothermal gradient because the sediments likely will have lower thermal conductivity due to less compaction. It takes time for temperatures to equilibrate.

Complicating modeling efforts are the variable subdivisions of the Earth's crust and lithospheric based on different thresholds (mechanical, compositional, seismic velocity, thermal, etc.). The depth of the asthenosphere can be somewhat constrained by the Moho discontinuity, which is seismically imageable and will be shallower than the asthenosphere. The depth to the Moho on oceanic crust




Fig. 15-2. A profile through the Earth with an inset view of the lithosphere. The three main sources of heat measured at the Earth's surface come from the asthenosphere, continental crust, and radioactive materials in the sedimentary section. On oceanic crust, the dominant source of heat comes from the asthenosphere and is a function of crustal age.

Sources: Profile adapted from Carpenter and Keane 2016, Fowler 2012.

will average around 5 to 10 km. The Moho depth will be between 20 and 90 km on continental crust (Hacker et al. 2015). A good average depth to the Moho on the continental crust is ~35 km based on various global potential field models and regional seismic lines. The asthenosphere is also generally aseismic due to its ductile or plastic character, so deep earthquake data may also provide an estimate for the base of the lithosphere. These data are freely available from agencies such as the USGS. In active rifts and oceanic spreading centers, the asthenosphere can be quite shallow, with a thin lithosphere. The lithosphere will gradually thicken away from the rifts to typical depths of more than 100 km (Allen and Allen 2005). In subduction zones, the depths to the Moho and asthenosphere are more difficult to resolve and thermally model.

Crustal type is also important because oceanic crust lacks many of the radioactive minerals that can provide appreciable heat within continental

crust. In most offshore areas, it may be difficult to know if an area is underlain by continental, oceanic, or some type of transitional/thinned continental crust (fig. 15–2). Many authors will delineate the transition as a continental-oceanic boundary or transition (COB or COT) (e.g., Allen and Allen 2005, Broad et al. 2012). There is a general observation that oceanic crust is usually found at water depths greater than ~3,000 m (~10,000 ft or 4.0 s TWT). This general bathymetric estimate can be very useful if there are no other regional data available (i.e., deep seismic, gravity, or magnetic data).

Thermal modeling should focus not only on matching temperature data but also on matching the thermal maturity of the sediments by incorporating the burial history for a given area (fig. 15–3). This additional complexity is needed for predictive petroleum modeling, but less so for geothermal exploration. Many sedimentary basins have been exposed to polyphase deformation throughout geologic time, with differing thermal regimes. Heat pulses may have occurred during past rifting events, whereas orogenic processes (i.e., mountain building) may have lowered the heat flow. Volcanism and igneous intrusions also cause localized temperature perturbations in the subsurface, all of which will impact the thermal models and thermal maturity (Allen and Allen 2005). Generally, sills or dikes will cause perturbations on the order of 1 to 2 times the thickness or width of the intrusion (Dow 1977). In contrast, regional volcanism related to subduction zones can cause regional variability (e.g., low geothermal gradients in the fore arc, while the arc and back-arc areas will have high geothermal gradients). Overall, thermal modeling is very difficult and time consuming but is necessary for predictive estimates of subsurface temperatures. It is worth the effort, with the realization that the solutions are nonunique and often yield medium to low confidence estimates.

Geothermal Resources

Geothermal resources are commonly classified into several categories (warm water, hot water/steam, and hot dry rock; fig. 15–4). Warm water resources are available in most regions of the world but may not be cost-effective (Barbier 2002). These resources are not produced in a conventional sense, but relatively shallow wells provide warm water that is circulated around a building or home to warm the building in the winter. Some more advanced systems also provide cooling options during the summer by transferring heat into the ground in the summer. This is the most common form of geothermal energy and is available through various companies. The cost of these systems can be expensive, and economic payback may take a long time. In some countries solar-heated versions of this system are installed on or near homes.

A hot water/steam geothermal system is the type of geothermal resource that often comes to mind when people think of geothermal energy, with visions of




Fig. 15-3. An example of four wells that have similar burial histories but with variations due to the potential source rock maturing at different times, depending on the cumulative thermal stress experienced (based on time-temperature index calculations and relationships from Waples [1980]). Even though well B is currently the deepest well, it was not the first well to generate oil because well D has experienced hotter temperatures for a longer period of time. This example also includes a salt canopy that was emplaced recently, which is reflected in the slightly lower geothermal gradients postemplacement (~1–2 Ma) in models A, B, and C.




Fig. 15-4. A schematic figure showing warm water, hot water/steam, and hot dry rock geothermal systems that can be used for power generation or home heating and cooling.

nearly hot springs, geysers, steam vents, and volcanos. This type of geothermal system usually is focused on generating electrical energy via one or more turbines driven by steam and hot water. To produce steam at pressures that will economically generate electricity, not only high temperatures (typically 100°C–350°C) are required, but also high geothermal gradients (to lower drilling depths/costs). The facility must also be located in reasonable proximity to the energy consumer. Hot water/steam systems also require a reservoir with high porosity and permeability, capable of flowing high rates of water or steam with minimal contaminants (Barbier 2002). The facilities will remain in operation longer if pressures can be sustained. Higher pressures will greatly help the rate at which water steam is produced and plant output. Lower pressure reservoirs or reservoirs with limited extent may quickly require pumps, and those extra costs may not be economically recoverable. There are many different development schemes used in hot water/steam systems. In some systems the steam, water, and vapor physically spin the turbine, and in others there is a heat exchange system that heats a low boiling point fluid that spins the turbine (Barbier 2002). The latter may not be as effective, but the turbine and machinery will require less maintenance. The number of wells and types of wells required will also differ among plants because the subsurface geology is different. Some plants may require numerous injection wells (if pressures or water rates drop too low), while others may not. As in conventional oil and gas fields, there will be a time when a plant will have to be abandoned due to decreasing economic returns.

The last type of geothermal system is hot dry rock, frequently referred to as an *enhanced geothermal system* or an EGS. Locations that can support large hot water/steam geothermal power plants are limited. Many places lack adequate subsurface reservoirs capable of producing high rates of hot water. EGS systems attempt to circumvent this issue by generating artificial reservoirs in areas with high geothermal gradients by using oil and gas drilling and completion techniques. This system relies on hydraulically fracturing a brittle formation or even basement and establishing an open fracture network between injector and producer wells. As water is injected into the hot reservoir, the water will be heated as it passes through the artificial reservoir and then is returned to the surface power plant via one or more producer wells. In ideal conditions, the systems will be a closed loop, with the produced steam/water being reinjected into the reservoir after cooling. EGS systems have the potential to be developed around the world, but costs can be very high (Barbier 2002). Many countries are considering EGS systems and examining different ways to drive down production and development costs, along with the length of time required to set up a facility.

Exercise

- 15–1) Gold and other precious minerals are commonly located within seams that can be related to the fault zones. Some of the deepest gold mines in the world are about 4 km in depth, where water-chilled air and oxygen must be injected in the mine to keep the air breathable and cool enough that workers can work safely. Assuming the formation or rock temperature limit of the mining operation in figure 15–5 is 50°C (122 °F) and the geothermal gradient does not vary appreciably over the area, at what depth would subsurface mining operations have to stop? Using this depth cutoff and the structure contour map, calculate the volume (bulk rock volume) of gold seam that can be accessed.





Fig. 15-5.

Questions

- 1) What are three common types of temperature-related maps?
- 2) Why do BHTs not reflect the actual in-situ formation temperature and require correction?
- 3) Well 41-067-20017 in the Swan Creek field has a surface elevation of 399 meters and was drilled to a depth of 3,631 ft TVDss. The corrected BHT was calculated as 47°C, and mean annual temperature of the area is 15°C. What is the geothermal gradient for this well?
- 4) What are three main categories of geothermal resources?
- 5) What five factors will help make a geothermal energy project economically feasible?