

PROCESS OPERATIONS

LESSONS LEARNED IN A NONTECHNICAL LANGUAGE



PENNWELL BOOKS

Contents

List of Figures	xiii
List of Tables	xvii
Letter from the Author	xix
Dedication	xxi
Introduction	xxiii
1. Applying Technology at Home.	1
Nucleate Boiling.....	1
High School Chemistry Lab.....	1
Heat Flux Limited Situation.....	2
Butane Vaporizer	2
Overcoming Flux-Limiting Heat Transfer Rates.....	3
2. Applying Technology at Work	5
Polymer Production.....	6
Vacuum Tower	7
Pumparound Optimization	8
Air Blower	9
Bad Fractionation.....	11
Cooling Water Flow.....	12
Low-reflux Rate	14
Spent Caustic Disposal.....	15
3. Optimizing Fractionation Efficiency	17
Distillation.....	17
Bubble Cap Trays	18
Optimizing Reflux Rate	18
Tray Weeping vs. Entrainment	19
Tray Pressure Drop vs. Flooding.....	19
Tower Temperature Profile	19
Color Discrimination	20
Closed-Loop Color Control on Earth	20
Gas Chromatography (G.C.) Closed-Loop Control	21
Spectroscopy as a Sensor	21
Fractionation Tray	21

4. Reflux in Distillation	23
Vapor Pressure Limitations	25
Two-Stage Distillation Process	26
Origin of a Distillation Column	27
Removing the Naphtha's Tail	27
5. Understanding How Distillation Trays Work	31
Entrainment and Tray Efficiency	32
Entrainment	33
Foam	34
Reflux	34
Downcomer Backup	34
Tray Efficiency	35
Benefit of Valve Cap Trays	36
6. Distillation: Converting Wine to Brandy, plus Basic Calculations	39
Relative Volatility	40
Solubility of Phases	41
Batch Distillation	41
Adding Distillation Stages	42
Mathematical Treatment	43
7. Distillation Tray Efficiency	45
Expanding Tray Capacity in Small I.D. Towers Without Retraying	46
Low Tray Efficiency	46
The Problem with Calculating Tray Pressure Drops	47
Theory vs. Reality	47
Determining Cause of Low Tray Fractionation Efficiency	48
Flooding Progresses Up a Tower	48
Varying Feed Rates at Constant Reflux Ratio	48
Back-to-Back Trays	49
Equilibrium Separation Stage	49
8. Steam Stripping Products	51
What Does Wet Steam Look Like?	51
Effect of Pressure	52
Effect of Temperature	52
Feeding the Stripper	52
What Are We Trying to Accomplish with Steam Stripping?	53
What's Inside the Stripper?	53
Packed Strippers	54
Tray Hole Areas	54
Drawing Samples	54
The Vacuum Tower	54

9. Draft in Fired Heaters	57
Draft: A Function of Density Difference	58
Effect of Temperature on Lift	59
Stack Draft	59
Effect of Stack Height	60
Don't We Need Fire to Create Draft?	62
Effect of Wind	62
The Venturi Effect	62
10. Hazards in Fired Heater Operations	67
Dangers of Positive Feedback Loop in Fired Heaters	69
The Danger of Variable Wind	70
The Point of Absolute Combustion	70
Effects of Air on Visbreaker Heater Outlet Temperature	71
Effect of Air on Boiler Steam Generation Rate	72
Location of O ₂ Analyzer	72
11. Coking in Fired Heater Tubes: Safe Shutdown Due to Tube Failure	75
Heater Tube Failed	75
Upper Explosive Limit	76
Snuffing Steam	76
Abandoning Box Steam Installation	77
Corrective Action	78
Heater Tube Coking	79
Mass Velocity	79
12. Centrifugal Pumps	81
Velocity, Head, and Pressure	83
Conversion of Velocity to Flowing Pressure	83
Function of a Centrifugal Pump Impeller	84
Converting Velocity to Head	85
Relationship of Head to Discharge Pressure	85
Pump Curve	86
Positive Displacement Pumps	87
Seal Oil Flow to Idle Pumps	87
13. Starting NPSH for Centrifugal Pumps	89
The Nature of NPSH	90
Nozzle and Piping Losses	91
The Bhopal Factor	92
Symptoms of Cavitation	92
Starting NPSH Requirements	93
Calculating Starting NPSH	95
Increasing Process Flow Rate	97
Increasing Available Starting NPSH	98
Practical Steps to Minimize Cavitation	98

14. How Controls Work	101
Temperature	102
Pressure	103
Levels	104
Flow	105
Control Valve Operation	106
Process Control with On-Stream Analyzers	107
Instrument Air	107
15. Dangers for Automated Control	109
Refinery Process Controls	109
Manual Intervention	110
Tower Pressure Control	111
Temperature Control	112
16. Heat Exchangers	115
Internal Bypassing	116
Vapor Binding	117
Flux Limits on Reboilers	118
Sensible Heat Transfer	119
Condensation and Condensate Backup	120
Blowing the Condensate Seal	120
Vapor Lock	121
Tube-Side Sensible Heat Transfer	121
Tube Roughness	122
Internal Bypassing	122
17. Cooling Towers: Minimizing the Water Return Temperature	125
Cooling Towers	125
Distribution Decks	126
Preventing Distribution Deck Fouling	127
Cooling Tower Efficiency	127
Airflow	128
Calculating How Much Water Evaporates	128
Airflow Problems	129
Cycles of Concentration	129
Cooling-Water Return Temperature	130
18. Cooling-Water Circuits: Maximizing Circulation Rates	133
Cooling-Water Systems	134
Water Pressure	134
Time, Temperature, and pH	135
Pressure Drop Survey	135
Frictional Loss in Water Piping	136
Hardness Deposits	137

Water pH Control	137
A Localized Restriction.....	137
Air Leaks in Suction	138
Approach to Wet Bulb	139
Washing of Hydrocarbon Liquids.....	140
19. Motive Steam: Use in Turbines and Engines	141
Enthalpy and Kinetic Energy	142
Critical Velocity	142
Source of Heat	143
Wet Steam Effect on Turbines.....	143
Reciprocating Steam Engine	144
20. Reciprocating Compression and Refrigeration.....	147
DeBottlenecking a Refrigeration Circuit.....	148
Refrigeration	148
Refrigeration Limit	149
My Home Air-Conditioner	150
Altering the Refrigerant Composition.....	151
Low Compressor Suction Pressure Limit	153
21. Hydraulics	155
Converting Potential Energy into Kinetic Energy	156
Frictional Losses.....	157
Variations in Orifice Coefficients	157
Centrifugal Pump Impeller and Volute	157
Pressure Recovery from Control Valves	158
Pressure Drop Surveys	158
22. Pressure and Pressure Drop in Pipes	161
Water Pressure	162
Pressure Drop	162
Pressure to Heat.....	163
Valves and Elbows	163
Converting Pressure Back to Height	163
Converting Water Pressure to Velocity	164
Frictional Losses in Piping	164
Using Pressure Drop Correlations	165
23. Vacuum System and Vacuum Surface Condenser Problems	167
Motive Steam Nozzle Malfunctions.....	168
Source of Silicates in Steam	169
Motive Steam Pressure	170
Seal Drum Problems	171
Air Leaks	172
Boot Quench Exchanger Leak.....	173

Velocity vs. Pressure in Steam Ejector	174
Vacuum Tower Surface Condenser	175
Surface Condenser Air Baffle.	175
Cooling Water Inlet Location	176
Third-Stage Surface Condenser.	178
24. Corrosion.	179
Origin of HCl in Refineries	180
Preventing Corrosion	181
Reformer Hydrogen.	181
Carbonic Acid.	182
Other Corrosive Agents	183
Significant Corrosion Failures.	183
25. Vessel Failure Due to Hydrogen Attack.	185
Non-Condensable Vent	186
Origin of Hydrogen Inside Vessels and Heat Exchangers	186
Examples of Hydrogen-Assisted Stress Corrosion Cracking	187
26. Energy Release by Combustion	189
Engine Horsepower	189
Air Temperature Affects Horsepower	190
Effect of Elevation	190
Effect of Moisture.	191
Compressing Combustion Air.	191
Fired Heaters.	192
Natural Gas-Fired Compressors	192
27. Case Histories: Avoiding Death and Disaster in Process Units	193
Raffinate Splitter Explosion	193
LPG Amine Extraction Tower Failure	195
Failure of Catalytic Cracking Unit	196
Bhopal Disaster.	198
Death by Nitrogen	200
28. Basic Safety Considerations	201
Autoignition	202
Nitrogen.	202
Hydrogen Sulfide	202
Pyrophoric Iron	202
Level Indication	203
Flooded Firebox	204
Steam Turbine Over-Pressure	204
Steam Turbine Over-Speed Trip	205
Water and Corrosion.	205
Color as a Temperature Indication.	205

Steam Condensate Drainage	206
Compressor Surge	207
29. Process Plant Operations and Global Warming	209
What's to Be Done?	210
Correct Use of VFD Motors: Driving Centrifugal Pumps	211
Excess Heater O ₂	211
Distillation	212
Steam Turbines	212
 Conclusion: Nature of Process Engineering	215
Index	217
About Oil & Gas Journal	221
Other Books by the Author	223
The Norm Lieberman Video Library	225

Figures

Fig. 2–1. Substituting a more volatile refrigerant increased refrigerant capacity.....	6
Fig. 2–2. Ejector “B” was flowing backwards	7
Fig. 2–3. Water level in kettle is higher than water level in glass.....	8
Fig. 2–4. Loose plug causes reduced turbine horsepower	9
Fig. 2–5. Trays 8-12 had low fractionation efficiency due to low vapor rates....	11
Fig. 2–6. Excessive elevation of a water cooler can cause air to flash out of water in the condenser tubes.	12
Fig. 2–7. Steam traps can either blow-thru or back-up. Either will reduce reboiler duty.....	14
Fig. 4–1. Light naphtha has an excessive end point.	24
Fig. 4–2. Ancient still. Yield reduction for increased product purity.	25
Fig. 4–3. Two-stage distillation apparatus increases purity without reduction in product yield.	27
Fig. 4–4. The air cooler is acting as a theoretical separation stage.	28
Fig. 5–1. Primitive distillation units three stages.....	33
Fig. 5–2. Distillation tray entrainment reduces tray fractionation efficiency.	35
Fig. 6–1. A single-stage still	41
Fig. 6–2. Two-stage still.....	42
Fig. 8–1. Side-stream stripper	53
Fig. 8–2. Steam Stripping Vacuum Tower Feed	54
Fig. 9–1. DRAFT = 0.45” H ₂ O).....	60
Fig. 9–2. Head pressure of 60°F water.	61
Fig. 9–3. Components of a natural draft fired heater.....	63
Fig. 10–1. O ₂ Analyzer located correctly below bottom row of convective tubes avoids effects of tramp air leaks	68
Fig. 10–2. Effect of tramp air leaks	72
Fig. 11–1. Stuffing steam could not be used when tube failed. It had been blinded due to water in steam.	77
Fig. 11–2. Heater snuffing steam correct design	78
Fig. 12–1. Pressure inside the pump case is the pump suction pressure. Pressure increases as liquid flows thru volute.	82
Fig. 12–2. Pump performance curve. Amps are proportional to motor horsepower.....	86
Fig. 13–1. Typical pump installation.....	90

Fig. 13–2. A sudden increase in drum pressure temporarily increases available NPSH for start-up.	93
Fig. 13–3. Manufacturer's pump curve showing required NPSH.	95
Fig. 13–4. Pumping water from a tank.	97
Fig. 13–5. Volume of 100ft, 8" diameter feed line	97
Fig. 14–1. Thermowell assembly	102
Fig. 14–2. Pressure guage	103
Fig. 14–3. Level indication	104
Fig. 14–4. Flow measurement	105
Fig. 14–5. Air to open control valve	106
Fig. 15–1. Level measurement by differential pressure.	110
Fig. 15–2. Measure level by $(\text{PRC-P}_3) \cdot (2.31) \div (\text{S.G.}) = \text{Feet above P-3 Guage.} \dots$	111
Fig. 15–3. Partly plugged pressure tap causes tower to over-pressure.	112
Fig. 15–4. Partly inserted thermowell causes false low temperature reading in sulfur plant start-up.	113
Fig. 16–1. Leaking pass partition baffle.	116
Fig. 16–2. Shell side seal strips improve heat transfer.	117
Fig. 16–3. Vapor binding reduces heat transfer.	118
Fig. 17–1. Induced-draft cooling tower.	126
Fig. 18–1. Induced-draft cooling tower	134
Fig. 18–2. Pressure drop survey.	136
Fig. 18–3. A buried valve partially closed restricted cooling water circulation. ...	138
Fig. 19–1. Turbine steam nozzle	143
Fig. 20–1. Refrigerant circuit	148
Fig. 20–2. Refrigerated reactor.	150
Fig. 20–3. Norman Lieberman in El Dorado, Arkansas starting up revamped refrigeration circuit -Jan-1968.	151
Fig. 23–1. Steam ejector developing sonic boost.	168
Fig. 23–2. Condensate back-up raises condenser pressure.	171
Fig. 23–3. Tube leak results in loss of vacuum due to steam overloading vacuum system.	173
Fig. 23–4. Velocity vs. pressure profile in steam ejector. Temperatures observed on outside surface.	174
Fig. 23–5. Vapour binding increases surface condenser operating pressure and reduces the turbine horsepower.	176
Fig. 24–1. Correct CO ₂ vent is thru PT. A- NOT PT. B to prevent carbonic acid corrosion and tube failures.	182
Fig. 27–1. Raffinate splitter-16 killed	194

Fig. 27–2. Lack of post-weld heat-treating results in death and disaster	195
Fig. 27–3. Fluid catalytic cracker unit vapor line failure due to quill location. . .	196
Fig. 27–4. Union Carbide Bhopal, India; 10,000 people killed	199
Fig. 28–1. DP÷S.G. Used to calculate level.	203
Fig. 28–2. Tube leak causes propane to sewer.	206
Fig. 29–1. Close horsepower valves to force governor to open and save energy. . .	213

List of Tables

Table 11–1. Tube-side coking resistance in relation to tube mass velocity	79
Table 17–1. Cooling tower performance standard	128
Table 26–1. Converting Degrees.	190
Table 26–2. Effect of moisture in the air	191
Table 29–1. Global Temperature Rise	209

Letter from the Author

I went to university from 1961 to 1964, and I learned nothing. It wasn't that I didn't try. Yet, I have been really successful as a process engineer in designing, operating, and—most importantly—troubleshooting refinery process problems for the past 58 years.

Most of the knowledge that I rely upon consists of things I've learned from troubleshooting home repairs, swimming pool maintenance, and air-conditioner problems. I am a real expert of any and all toilet hydraulic failures.

Also, I had a wonderful high school science education, which I apply all the time—like, $PV = NRT$ and 34 feet of water = 1 Bar.

This book wouldn't be possible without the support of the *Oil & Gas Journal*. Throughout my career I have contributed many articles and the foundation of this book comes from the “Beyond back-to-basics: Process principles and concepts” article series.

I hope my book helps you in your job in the process industry.

Norm Lieberman
Chemical Engineer
norm@lieberman-eng.com

Introduction

I began my refinery troubleshooting career as a child, by wondering and worrying about the ordinary things that other, more normal children take for granted—things such as the steam radiator heater in the bedroom I shared with my older sister, how a drop of water dances around on the surface of a smooth frying pan, and why the water level in our toilet bowl would rise and lower a bit on very windy days. As a young boy, I had very little purpose in observing these oddities of the world around us. I suppose, in retrospect, that my interest in water, fire, wind, and air, was an outgrowth of a lack of cell phones, email, television, and microwaves—things that did not exist in 1948, when I was 6 years old. But perhaps the lack of exposure to the “Age of Computers” permitted me to develop the skills that I will be explaining to the readers of this book in the following chapters.

The purpose of this book is to tell process technology stories relating to things that have happened to me. I’m mainly interested in processes such as:

- Combustion
- Evaporation
- Flow of fluids
- Corrosion
- Solubility
- Boiling
- Vaporization
- Condensation
- Heating
- Pressure
- Refrigeration
- Cooling

My real passion in life is *steam*. Many of my stories concern this theme:

- Steam reboilers
- Steam turbines
- Steam vacuum ejectors
- Reciprocating steam engines
- Stripping steam

Process operation and engineering are complex branches of human knowledge. The process operator or engineer designs, operates, and troubleshoots the following:

- Petrochemical plants
- Refineries
- Pharmaceutical plants
- Food processing facilities

- Distilleries
- Steam and power plants
- Waste water treatment
- Water purification plants
- Hazardous waste disposal units

Their work has a lot to do with these topics:

- Combustion
- Chemistry
- Plumbing
- Thermodynamics
- Corrosion
- Hydraulics: Fluid flow
- Vapor-liquid equilibrium
- Heat balance
- Process control

I've related my observations drawn from everyday life into stories that I have applied to process problems. The key to safety and profitability in process units is to understand how things function. My success as a process engineer is a consequence of the ability to solve process plant problems using simple methods and grade school calculations. This is not a result of my engineering degree. It's based on observations I have made in all kinds of circumstances:

- As a child in our kitchen in New York
- Caring for my swimming pool in Louisiana
- Repairing toilets in my house in Illinois
- Studying a steam radiator in my bedroom in Washington
- Trips on a river steamboat on the Mississippi River
- Considering how my fireplace draws in combustion air in Texas
- Watching swirling water in a river in California
- Flying a kite
- Operating a microwave
- Watching water boil in an old frying pan

Geared to young and seasoned professionals alike, *Process Operations: Lessons Learned in a Nontechnical Language* is designed to present a straightforward approach to mastering the principles and concepts all process engineers should be able to apply without the need of a computer. While simulations and models are useful for examining long-term operational issues, they cannot replace the dimension of human logic and reason required when tackling the array of complex—and sometimes life-threatening—situations that occur in process plants. Using experiences from my more than 58-year career in the process industry, *Process*

Operations: Lessons Learned in a Nontechnical Language provides approaches to understanding core process concepts in ways that will equip the engineer to walk out of an office into a plant and directly resolve process deficiencies via small operational changes or simple retrofits.

The book is setup to be an on hand reference for you. It is not necessary to read it in sequential order. You will find the format of each chapter to be the same. Each chapter begins with an introduction of the subject followed by a purpose. Once each topic is explained the chapter closes with a Lessons Learned section.

1

Applying Technology at Home

Nucleate Boiling

I had just bought a new mug at Walmart; it was smooth and shiny, with no scratches. I filled the mug with water and put it in the microwave for 5 minutes. Nothing happened—the water did not boil. Puzzled, I set the very hot mug on the counter. Nothing happened.

I dropped a tea bag into the “super-saturated” water. The water exploded out of the mug with tremendous violence. The rough surface of my tea bag had provided sites for nucleate boiling to be initiated.

My mom had two frying pans. One was a very old, scratched pan that she inherited from her grandmother. She also had a new, smooth, stainless-steel pan—a present from my dad. If I heated the old pan on the stove for 10 minutes and gently dropped a tablespoon of water on the hot surface, the water would flash to steam and be entirely evaporated in a second.

If I heated the new, smooth pan on the stove for the same 10 minutes and, again, carefully deposited a tablespoon of water on its hot surface, the water would dance around on the pan without boiling. It would slowly evaporate over a period of several minutes.

Strange to say, the hotter the new stainless pan got, the longer it required for the tablespoon of water to evaporate. But, for the old cast iron pan, the hotter it was, the quicker the water would evaporate.

High School Chemistry Lab

The main purpose of attending high school is to meet girls. A secondary objective is to learn to use “boiling stones” in the chemistry lab. If you forget, when you attempt to agitate a flask’s contents with a stirring rod, the contents may explode in your face.

This often is not a problem. If the lab flask is old and scratched, nucleate boiling sites probably already exist. Boiling stones, which provide these points where vaporization can be initiated, are not needed.

Low-reflux Rate—El Dorado, Arkansas




Fig. 2-7. Steam traps can either blow-thru or back-up. Either will reduce reboiler duty.

- **Limit**—Fractionation was poor because of low-reflux rates. When the reflux rate was raised, the reflux drum level declined, and the reflux pump lost suction.
- **Background**—The problem of the low-reflux rate was lack of reboiler duty. That is, the reflux comes from the reboiler vapor. Reboiler duty is low because either (a) team condensate is backing up, or (b) steam is blowing through the exchanger. That is, “loss on the condensate seal,” due to a steam trap malfunction.
- **Solution**—To discriminate between these common problems, I slowly began to close on the steam condensate outlet flow. Simultaneously, using my infrared temperature gun, I monitored the reboiler process outlet temperature (T-1) (Fig. 2-7). If the problem was condensate backup, this would lower the process outlet temperature.
If the problem was steam blowing through (i.e., loss of the condensate seal), this would increase the process outlet temperature at T-1.
In this instance, the problem was improper maintenance of the condensate seal, due to a faulty steam trap, which was blowing through.
- **Follow-up**—Best to have a condensate drum and then pump the condensate to the collection system. Steam traps can either blow through, or fail closed, and cause condensate backup.

I'm currently working for Carl, the technical manager of an 80,000-BSD refinery in the Midwest. Carl's problem is bad fractionation in a naphtha fractionator. The tower makes two products:

- Light naphtha—Feed to a pentane-hexane isomerization unit, that changes straight-chain molecules to branched chains. Too many heptanes will coke-up the catalyst.
- Heavy naphtha—Feed to a naphtha reformer. Benzene precursors will increase benzene in gasoline product to an unacceptable level.

Fractionation will now either get better or worse as I apply the above procedure. If it gets better, it means that fractionation efficiency was being degraded due to tray deck weeping. If the separation efficiency degrades at higher rates, the problem was entrainment or flooding. If it improves, then the problem was tray deck weeping.

Back-to-Back Trays

The edge of each tray panel is bent down by 90 inches. Then the vertical edges are thru-bolted together. This creates, in effect, a half of an I-beam support at the edge of each tray panel. This type of assembly greatly increases the rigidity of the tray panels, and reduces the tendency of the tray to sag and hence develop low tray efficiency, especially at reduced vapor flow rates.

Equilibrium Separation Stage

I was the first person in history to design a complex fractionator that was actually constructed using a digital computer program. By complex fractionator, I mean a distillation tower that had multiple side-stream product strippers and draws, multiple pumparounds to remove heat, and several feeds (both vapor and liquid).

The tower was the “B” delayed coker at the American Oil Refinery in Texas City. Designed in 1966 and commissioned in 1968, it's still in operation at the Marathon Refinery (as of 2021). I visited it just last year. You can see it from Farm-to-Market Road 1764.

I had to create my own computer program in those early days of digital technology. Each theoretical stage (or tray) I represented by one *equilibrium separation stage*. This consisted of mixing liquid from the stage above with vapor leaving the stage below, at 100% mixing efficiency—then, separating the resulting mixture of phases, with 100% separation efficiency. Both the enthalpy of the vapor and liquid, and the molal components of vapor and liquid, I assumed were perfectly mixed.

“Okay! I’ll be right over. Don’t forget the pass steam. We don’t want to coke up the tubes.”

Upper Explosive Limit

I stood on the Mississippi River levee, 200 feet back from the heater. Black smoke blew out of every sight port, and oily flames raced from the stack. Tom was blocking in the fuel gas and lining up the pass steam to the coils to blow out the residue before it coked up.

Barry was closing the 4-inch heater feed valves on all four passes and making sure the control valve bypasses were shut.

It looked bad. But, in reality, the heater was in a safe position, because the heater firebox was in a fuel-rich situation above its upper explosive limit. It was too fuel-rich to explode.

I knew this because I could see unburnt hydrocarbon vapors from the failed tube igniting in the flue gas that was racing out of the heater’s stack. Of course, the concentration of hydrocarbons in the firebox would diminish with time as Barry blocked in the feed and closed off the fuel. And then, as the fuel-to-air ratio diminished, the heater box would drop into the explosive region. And then—the box would explode. I had seen this happen before.

Snuffing Steam

Barry should have introduced snuffing steam into the firebox at this time. This would have retarded the airflow into the firebox, and allowed the box to cool off in an air-deficient environment. That is, the steam would have raised the box pressure above atmospheric pressure and temporarily precluded airflow into the box due to draft.

But I knew Barry would not do this. A few months back, I had the snuffing steam lines blinded off from the visbreaker heater.

But why?

Because the snuffing steam lines were full of steam condensate. Their use would have blown water into a 1600°F brick box and created a pressure surge, which would have blown burning visbreaker tar all over the plant (Fig. 11–1).

I had suggested to Barry that, in the event of a tube failure, he instruct the operators to close off the air registers underneath the heater and shut the stack damper. This would prevent an explosive mixture of air and fuel from developing inside the firebox.

“Okay, Lieberman. In the event of a busted tube, I’ll call you to close off the damper and air registers. I’m not gonna ask any of my guys to risk their lives.”

Increasing Available Starting NPSH in Casper, Wyoming Refinery

“Joe, first we’ll increase the drum set point pressure by 10 psi.

“Next, we’ll open the discharge valve (see Fig. 13–2) by one quarter of a turn.

“Then start the pump, and open the discharge valve, in just a few minutes, all the way,” I said.

“No, Norm. That can’t help. The suction pressure will increase by 10 psi. But the vapor pressure of the flashed crude will increase by the same 10 psi. According to your equation (1), the increased vapor pressure of the flashed crude will offset the higher suction pressure.”

“Joe, after 10 minutes, what you say is true. But, at first, due to the 10-minute residence time of liquid in the drum, the higher vapor pressure liquid, formed at the vapor-liquid interface, will not migrate into the pump suction for that 10 minutes. If you can get the pump up and running quickly, you will have a temporary surge of available NPSH.

“Joe, it’s a startup trick that I’ve used. Best to design the equipment elevation properly and allow for the starting, as well as the running, NPSH requirements. Often, while operators are learning this trick, they repeatedly cavitate the pump and damage the \$75,000 seal.”

Practical Steps to Minimize Cavitation

“Joe, these are steps to protect mechanical seals from damage due to cavitation:

1. Place a pressure gauge with a red mark on the pump suction. Train the operators to open the pump discharge valve as fast as possible, consistent with the pressure not falling below this red mark.
2. Raise the suction drum pressure rapidly by a few psi, just before starting a pump. Then reduce the pressure very slowly once the pump is operating.
3. During normal operations, increase flows really slowly. Most experienced operators tend to do this by themselves.
4. Run near the maximum safe drum level.
5. Spray cold water on the pump case and suction line to subcool the liquid.
6. Running two pumps in parallel requires a lot less NPSH—but is often difficult to control.
7. Injecting a subcooled liquid slip-stream into the pump suction will increase available NPSH.
8. A discharge spill-back to the suction line diminishes the available NPSH and also increases the required NPSH.